

IMPORTANT WEEKLY CLEANING ROUTINE FOR 'SCOTSMAN' SELF CONTAINED ICE MACHINES



1. Turn machine off at the mains.
Empty the ice bin. (If it is not convenient to discard the ice, you can transfer the ice to a freezer using a clean plastic bag as a container).

2. Reach inside and remove the plastic water curtain by pulling gently towards the front to release it from its plastic spigots.
(Note which way round it fits for re-assembly).

3. Wash down the inside of the bin, the curtain surround and the water curtain with a non abrasive cleaner. Rinse thoroughly with fresh water.

4. Mix 5 litres of clean water with 5 capfuls of Suma 'D10' cleaner sanitizer and, using a clean sponge or cloth, wipe down the bin inside and out, the water curtain and its surround. Rinse out the sponge or cloth frequently in the solution.

DO NOT RINSE OR DRY


The solution is odourless and tasteless.
Wiping dry may well re-contaminate.

5. Pour half a litre of the anti-bacterial solution into the bin's drain to keep it clean and clear of obstruction.

6. Soak the water curtain, ice scoops and other utensils in the remaining solution for 90 minutes.

7. Refit the plastic water curtain without further drying or rinsing making sure that the raised surface of the plastic fingers face outwards.

8. Close bin door and turn machine on to return to normal operation.



In case of query please call 01473 350045

**ALWAYS KEEP BIN DOOR CLOSED
EXCEPT WHEN GATHERING ICE**

These guides are to supplement manufacturers procedures for cleaning and should not be considered as definitive.

Do not mix different cleaners, observe at all times manufacturers safety precautions.