

# IMPORTANT DAILY CLEANING ROUTINE FOR 'SCOTSMAN' TC180 ICE DISPENSER'S

1. Wipe the exterior of the machine with a disposable sanitizing wipe or D10 and a disposable cloth. Also, clean any external air louvers/grills of the machine.

2. Remove the ice spout and allow to soak in a sanitising solution for 10 minutes. Then rinse well with fresh water – DO NOT WIPE DRY !

3. Ensure that the underside dispense area is thoroughly cleaned and sanitised. Clean the ice chute area using a sanitised 'bottle' brush.

4. Remove the drip tray and allow to soak in a sanitising solution for 10 minutes. Then rinse with fresh water – DO NOT WIPE DRY !

5. Clean & sanitise the drip tray area.

6. To clean the drainage system, pour hot soapy water or sanitising solution into the drain pan ensuring not to overflow the tray.

7. Using a sanitised brush, carefully insert into the drain hole to clear any solidified build up of debris from the drain tubes by using an in & out circular motion.

8. Replace the drip tray and ice spout.

NOTE – If the unit is isolated from the electrical supply, there will be a 3 minute delay prior to the ice making mode beginning

**In case of query please call 01473 350045**

**ALWAYS KEEP ICE DISPENSE AREA CLEAR,  
EXCEPT WHEN GATHERING ICE**



These guides are to supplement manufacturers procedures for cleaning and should not be considered as definitive.

Do not mix different cleaners, observe at all times manufacturers safety precautions.